



GAMES, ENTERTAINMENT & INFLATABLES EQUIPMENT HIRE INSTRUCTIONS & SAFETY

Thanks for choosing McHugh Hire, please take a minute to read the applicable instructions relating to the equipment you have hired.

We're sorry if some of the info sounds like common sense, but we need to cover all the bases. We've tried to translate the instructions for our equipment into a language that people can understand, if any part of it doesn't make any sense, please let us know and we'll fix it.

Please make sure you have fully read the instructions and all terms and conditions and product info at www.mchughhire.com before using any of our equipment to avoid extra cleaning, hire or damage charges.

All of our equipment and equipment's packaging must be returned in the same condition as it was delivered or the hirer will be charged for replacement. All equipment and packaging must be properly cleaned before return unless otherwise stated or paid for.

All equipment is for adult use only unless otherwise stated.

DO NOT LEAVE OUR EQUIPMENT OUT IN THE RAIN.

When you have finished with your equipment please make sure everything is wiped down and cleaned in the same condition you received it. If your equipment is returned un-clean you will be charged for cleaning.

For equipment lost or damaged by misuse you will be charged for replacement or repair.

It is your responsibility to ensure all power leads will not be a trip hazard, we have safety cable covers for hire if required. Please also make sure your leads are clear of water, heat and any other hazardous source. If you have hired RCD safety switches or blocks, please test the devices by pressing the trip button(s) before using each day.

For any equipment that comes with spare parts/batteries/bulbs etc:

Do NOT discard the original/dead parts/batteries/bulbs. They must be marked "dead" and returned with the equipment for our post hire testing. Failure to do so will incur a replacement charge on return. Missing AA, 23A, AAA batteries will be charged at \$2.50 each. All other missing parts will be charged at RRP.

All equipment must be packed away, at loading area, ready for our drivers to pickup.

You are responsible for using our equipment safely, especially equipment that produce heat. Please use common sense and keep children supervised near all McHugh Hire equipment.

Please note many of our items contain GPS tracking units to prevent theft and to recover stolen equipment. This includes all of our expensive equipment and random lower cost items. If you are using the equipment in a high security area, please check that these transmitters won't be a problem on site.

Jumping castle hire:

Before you setup the castle, check your setup area for the following:

- Check the area is flat and smooth and not on an angle.
- Check there are no rocks or sharp objects that could puncture the castle.

- Check there are no walls/buildings/trees/fences etc. that the castle could rub on the side. You will need a minimum of 500mm extra space around the castle for movement and pegging/weighting. Check the website for your castle's dimensions.
- Check there is nothing above (powerlines/tree branches etc.) that the castle could touch when inflated.

To setup your castle, lay out your ground cover first over the area the castle will be inflated. Then unfold your castle over the ground cover. Attach blower motor with the provided zip-ties to the filler tube and fill the castle.

Once filled, hammer in your ground pegs (or attach weights if ground pegging is unavailable) then ensure the castle is secured properly.

Once inflated you must inspect all sides and above the castle to ensure it will not be rubbing on anything during use and that there is a minimum 500mm clearance.

Adult supervision is required at all times. Shoes must not be worn on the castle and socks must be worn at all times. No other items should be on the castle to ensure the safety of jumpers. Please see the McHugh Hire website for the maximum weight limit of your castle.

When you have finished with the castle, the outside and inside must be cleaned with hot soapy water while inflated (unless cleaning has been paid for). Then when the castle is dry it must be folded up and placed back into the provided transport bag. Please remember to place the steel ground pegs into the blower motor box for transport. Please also check the ground cover tarp is clean and dry before folding up.

Sky-dancer hire:

Before operating, please observe your surrounds and ensure there won't be any objects that could rip the dancer's material (trees / buildings etc).

Please try and keep the dancer off the ground as much as possible when setting up and packing down the unit.

Place the fan on the ground and attach the bottom of the dancer to the fan, unroll the dancer and start the fan. Once operating, observe the dancer and ensure it is not touching anything and is staying upright.

Please do not use the units in high winds or rain.

Games hire:

Please take note of the number of pieces / bags / containers / boxes and everything that is delivered and how it was delivered as this is how it is to be returned. Game parts are one of the most lost pieces of equipment we hire and most of them have expensive replacement costs. Some can't even be replaced without purchasing the whole game again.

Please supervise children at all times, especially with our giant games to avoid injury.

We wish you all the best and thank you for choosing McHugh Hire for your hire needs!

If you have any great photo's of our equipment in action we'd love you to share them with the McHugh Hire community via our Facebook page <https://fb.me/McHughHireShop> or email bookings@mchughhire.com

If you have any queries please call us on 6162 1662.

